



#### Technical requirement

1. Before assembling, all parts should be clean, no dirty or grease. remove all burrs and sharp edges.
2. Handle should turn or close freely.
3. After assembling, test by water at pressure no less than 0.6MPa, no leakage.

18	13. 20302. G15. 9050-1520	PACKAGING	1			
17	12. 10102. 015. 6500	SCREW	1	HPb59-3	2g	S9xM6x5
16	12. 10102. 015. 82	O-RING	1	EPDM	1g	φ7.1Xφ1.6
15	12. 10102. 015. 88	CHECK CORE	2	ABS	3g	15MM
14	12. 10102. 015. 6600	SPRING	2	304	1g	φ16.5Xφ1.2
13	13. 20332. G15. 82	O-RING	1	EPDM		φ18xφ2.4
12	13. 20302. G15. 5350	LOCK CAP	1	HPb59-3	11g	BRASS COLOR
11	13. 11112. G15. 5750	NOZZEL	1	HPb59-3	12g	BRASS COLOR
10	13. 20202. G15. 7050	HANDLE	1	HPb59-3	25g	BRASS COLOR
9	16. 11002. G20. 6530	SCREW	1	Q235	1g	M5x6.5 BRASS PLATING
8	16. 11002. G15. 5000-1140	NUT	1	HPb59-3	5g	BRASS COLOR
7	13. 20202. G15. 81	PACKING	1	GRAPHITE	1g	φ12.5xφ8.6x6
6	13. 20302. G15. 1750	BONNET	1	CZ132	48g	BRASS COLOR
5	13. 20302. G15. 84	WASHER	1	RED FIBER		φ30Xφ24x1
4	16. 20102. 015. 8700	STEM	1	HPb59-3	35g	BRASS COLOR
3			1	HPb59-3		BRASS COLOR
2	16. 20102. 015. 80	WASHER	1	EPDM	1g	φ18.5Xφ5X3
1	13. 20302. G15. 0750	BODY	1	CZ132	123g	BRASS COLOR
NO	ITEM	NAME	QTY	MATERIAL	WEIGHT	REMARK